TIMER Short key press ↓	Long key press after selecting function on left	**SET** Short key press ↓	Long key press after selecting function on left	**ALTI** Short key press ↓	Long key press after selecting function on left	**SET** (Preferences) (After long <u>initial</u> press) Short key press ↓	
Time Clock →	Set time	**Averager** →	Stay on averager	**ALTI 1** →	**Set to zero**	**Set averaging period**	*Use* ∧ *and* ∨ *to increase and decrease settings.*
Alarm Timer →	Set alarm period	**G-Meter**		**ALTI 2 (QNH)** →	**Set to height ^ v**	**Volume**	
Stopwatch Autostart →	Autostart on	G-Meter Max →	Reset G-Meter		(Short press)	**Up Threshold**	
Stopwatch Start		**Temp deg C** →	**Temp deg F**		**Set to pressure ^ v**	**Find Threshold**	← (Thermal Finder)
Stopwatch Stop →	Set to zero	Lift Max →	Reset		Set	**Down Threshold**	Long key press after selecting function on left ↓
		Altitude Max →	Reset			**Damping Factor**	
		Sink Max →	Reset	**Barometer** →	**Pressure trend**	**Pace of tones**	
		Altitude Minimum →	Reset		(Long press)	**Units M/Ft/Mixed**	
		Battery level →	Battery voltage		Zero trend	G-Meter Set up →	Start set up procedure
						Serial number →	Go to start of menu
				QNE →	Adjust after 10s press	**Restore Defaults** →	Restore

Clock reverts back after 3 S

Averager reverts back to ALTI after 10 S

Alti type will be stored when switched off.

Press ALTI if you are already USING the SET menu, then press SET for 2 seconds to enter the **preferences** menu.

Main functions are shown in bold text.
Last function used follows averager on SET button.
Please refer to the manual for more information.

Micro Alti   Quick guide